


Installation, Operation & Maintenance Manual

GPS-iRIB[®]-18 & GPS-iRIB[®]-36



NOTICE: This product is to be used only as directed. Read entire manual before use. Do not use unless properly installed.



gpsair.com

For technical product queries, please reach out to techsupport@gpsair.com

Thank you for purchasing a GPS-iRIB® air ionization system from GPS Air. The GPS-iRIB is a highly versatile device designed to be installed on the coiling coil of ductless systems or PTACs. The units can be installed on systems where there may not be enough room between the filter and the coil for traditional GPS products. The units come with adhesive-backed hook and loop tape for ease of installation.

As part of the installation process, a Startup Document should be completed. For the latest version of the document, visit our website or utilize the QR code.



Ductless Mini-Split and PTAC Mounting and Wiring Instruction

1. Turn off the power to the air handling unit (AHU). Follow all local and national electrical and building codes.
2. Remove the filter screens and the cover to expose the coil surface and the power box.
3. Determine where you want to mount the ionization strip on the AHU.
4. Peel off the loop section from the GPS-iRIB and then peel off the paper layer to expose the adhesive.
5. Carefully attached the adhesive backed loop on the AHU at the desired location. Some mini split systems come with a plastic strip along the top of the coil. If so, mount the GPS-iRIB to the plastic strip. Otherwise mount the GPS-iRIB on the finned surface. See [FIGURE 1](#).



CAUTION: *Keep the emitter tips away from loose wires or any grounded parts.*




CAUTION: MAKE SURE POWER IS DISCONNECTED TO THE HVAC EQUIPMENT BEFORE INSTALLATION

6. Each AHU brand will have different space constraints for the power supply. Find an appropriate space to mount the power supply using the included hook and loop tape. Press the power supply firmly to the mounting location. See [FIGURE 1](#).
7. Run the wires to the electrical compartment. Connect the black wire to 100-240VAC and the white wire to neutral. For 208-240VAC installations, connect the white wire to the other hot leg, depending on the power supplied.
8. Trim the wires to length and connect to the appropriate power terminals, normally L1 and L2. Secure wires properly with wire ties or other NEC approved methods.



gpsair.com

Figure 1



Operation

1. Turn on power to the AHU.
2. The ion device will be powered when power is applied to the AHU. Note: the ion device is designed to remain energized 24/7 and does not have to cycle with the fan.
3. Once unit is energized, the integral LED on the power pack will illuminate, indicating the unit is active.

BAS Alarm Operation

1. The purple wires connect to the integral alarm relay. When the unit is powered and there are no faults, the alarm contacts will be closed. When there is a fault, the contact will open.

Maintenance

1. Remove power from the AHU and remove the required parts to access the iRIB. Confirm the iRIB power supply LED is not illuminated. It is good practice to ensure all voltage is removed from the iRIB. Take a screwdriver with insulated handle and touch a carbon fiber brush brass connector on one side to another on the opposite side. This will discharge any remaining voltage that could cause a potential shock hazard during maintenance.
2. Use a wet wipe or damp cloth to clean the iRIB. A soft bristle brush, like a toothbrush, can also be used to clean debris from ion emitters. Do not expose the iRIB to corrosive cleaners.



Note:

In order to prevent damage to the emitter tape, the should note be folded over onto itself.

An iRIB-18 should be fitted to a coil/substrate that is continuous and at least 18" long. Where the coil/substrate exceeds 18", the polyimide tape emitter portion of the iRIB should be centralized on the substrate it is to be attached to.

An iRIB-36 should be fitted to a coil/substrate that is continuous and at least 36" long. Where the coil/substrate exceeds 36", the polyimide tape emitter portion of the iRIB should be centralized on the substrate it is to be attached to.

Product Registration

By registering your order, the standard limited warranty on eligible products from your purchase is automatically extended to 3 years, at no additional cost.

Register your products at www.gpsair.com/product-registration or scan the QR code.




The information provided in this manual is up to date at the time of printing. Any revisions to this document will supersede the content included. For the latest applicable version of this manual, visit our website or utilize the QR code.



gpsair.com

3101 Yorkmont Road • Suite 1500
Charlotte, NC 28208
980-279-5622



To access a list of applicable patents,
please visit www.gpspatents.com

